

Speaker Set Instructions


Amplified Speaker Set, Model SPK 850

OVERVIEW

You can connect the the SPK 850 Speaker Set to a variety of audio sources, including CD players, tape players, and computers.

SETTING UP THE SPK 850 SPEAKERS

- Step 1: Connect the audio cord to your audio source.
- Step 2: Connect the speaker wire to the unpowered speaker.
- Step 3: Plug the AC power cord into an 120 VAC outlet. Turn the power switch on.
- Step 4: Adjust the volume and tone controls to your preference.



WARRANTY

The SPK 850 Speaker Set is warranted against defects in manufacture for a period of one (1) year. See the enclosed warranty card for details.

SPECIFICATIONS

Dimensions:	5- $\frac{1}{2}$ " W x 8- $\frac{3}{8}$ " H x 5" D (14 cm x 21.3 cm x 12.7 cm)
Total Weight:	8.1 lbs. (3.67 kg)
Color:	Black
Power:	120 VAC, 50 or 60 Hz, 25 Watts
Loudspeakers:	4 inch, 8 Ω , wide-range
Controls:	ON/OFF rocker switch, rotary volume, bass, and treble controls
Optional Floor Stand Kit:	SS-3 Floor Stand Kit
Optional Wall Mount Kit:	SB-3 Wall/Ceiling Mount Kit