

WaveCAST Receiver

WF R1

INSTALLATION INSTRUCTIONS

For WaveCAST Systems



Audience members can listen to WaveCAST audio on the WaveCAST receiver instead of using the WaveCAST app on their personal device. The WaveCAST Receiver can be used for listeners who cannot or do not want to install the WaveCAST app on their phone, or to meet legal assistive listening requirements (such as ADA or IBC regulations)

Settings Menu

The settings menu allows you to adjust device settings such as screen brightness and network connections.

Press the gear button to open the Settings menu. The following options will be available:

Wi-Fi

You will need to connect the receiver to the WaveCAST Wi-Fi network before the app can be used.

To create a connection, select your Wi-Fi network and log in, if necessary.


Brightness

To adjust the screen brightness, slide the brightness slider to the right for a brighter screen, or to the left for a dimmer screen.

Language

To select an alternative language, select language and download the language pack desired.

Note: Changing the system language does not affect the language of the WaveCAST app itself.



Using the WaveCAST App


The app will start once the product is turned on. It is nearly identical to the app a listener may download on their personal device.

If it is your first time starting the app, you will need to use the Settings Menu to create a Wi-Fi connection.

Once you have a Wi-Fi connection, the receiver will search for available WaveCAST channels. When you press the Channel button, a list of channels appear. Select the channel the user should listen to.

If no WaveCAST channels are available, a message stating “no channels detected” will pop up. The app will still display the channel search screen, but no channels will be available to select.

When listening to streaming audio, the user can adjust the volume from the listening screen.



Charging the Receivers

The WaveCAST Receivers can be charged in an approved charging bay available from Williams AV or via a USB-B cable.

NOTE: If the receiver has been unused for three months or longer, check to make sure the charge status is 50% or higher. If the charge status is below 50%, charge the receiver fully before using it. Do not leave WaveCAST Receivers unused for extended periods of time.

Recycling Instructions



Help Williams AV protect the environment! Please take the time to dispose of your equipment properly.

Please Recycle

Please do NOT dispose of your equipment in the household trash. Please take the equipment to a electronics recycling center for proper disposal.

Regulatory Statements



Caution: Unauthorized modifications or changes not expressly approved by Williams AV could void compliance with regulatory rules, and thereby your authority to use this equipment.

United States FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

FCC ID: CNMWFR1

Canada IC

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC: 1360A-WFR1

Japanese Standards



この装置は、クラスA機器です。この装置を住宅環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。VCCI-A

This is a Class A equipment. Operation of this equipment in a residential environment could cause radio interference. In such a case, the user may be required to take corrective actions. VCCI-A



R 210-132314

WILLIAMS AV

info@williamsav.com / www.williamsav.com

800-843-3544 / INTL: +1-952-943-2252

© 2021, Williams AV, LLC MAN 250C